

ICBKT-WA-4200 In-Ceiling Bracket for the WA-4200 Access Point

INSTALLATION GUIDE

WA-4200 In-Ceiling Bracket

This bracket allows recessed mounting of the WA-4200 access point.

Package contents: WA-4200 bracket, cutout template, Quick Start Guide

Installing the bracket

1 Remove the backing from the included cutout template and affix it to the ceiling where the AP will be installed.



- **2** Use a drywall saw to cut along the template's dotted line, then fish the PoE Ethernet cable from inside the ceiling so it's easy to grab when mounting the bracket.
- **3** Hold the bracket near the mounting hole, then feed the Ethernet cable through the cable opening.
- **4** Make sure that the in-ceiling bracket's mounting latches are in their closed position.



5 Insert the in-ceiling bracket into the opening you created in step 2.



6 Using a Phillips screwdriver, press each spring-loaded dogleg lever in, then 1/4 turn clockwise until the lever is perpendicular to the bracket edge, then release it. The spring-loaded doglegs hold the bracket securely in place.



Mounting into the in-ceiling bracket

- 1 Connect the Ethernet cable to the Ethernet port on the AP, then slide the AP into the bracket's swivel door until it locks into place.
- **2** Press the AP into the bracket until it clicks into place.
- **3** To mount the AP into the bracket, see the visual guide on the following page.



Removing the AP from the in-ceiling bracket

- 1 Push the AP into the bracket to release the swivel door.
- **2** Pull the swivel door's center tab with your thumb, toward the bracket, then push the AP toward the bracket.





Technical Support

For technical help:

www.pakedge.com support@pakedge.com (650) 385-8703

For regulatory information: *www.pakedge.com/regulatory*



11734 S. Election Road Draper, UT 84020 Main: (650) 385-8700 Fax: (650) 685-5520

www.pakedge.com sales@pakedge.com ©2020 Control4. All rights reserved. Latest version at pkdge.co/wa4200-bracket



200-00646-A.1 2020-08-28 TW